

# Ankle Attacker

## CTE-AAMT

Thank you for your purchase. The CTE Ankle Attacker is a high flow air device for haunted house or fun house use. The Ankle Attacker is a great addition to any professional haunted house or home haunt. The Ankle Attacker runs on standard 110VAC power and compressed air. When triggered, the device will deliver a very loud and forceful blast of air. The effect is extremely startling, and will surprise the most hard to scare patrons.

CTE constructs products using high quality components and parts. The Ankle Attacker was designed and built to last many years. All CTE products carry a one (1) year warranty. The Ankle Attacker is equipped with a seven (7) gallon air reserve tank, steel pipe with Teflon seals, air gauge, safety valve, high quality electronic valve, 10' power cable and a handheld remote control.

The CTE Ankle Attacker is shipped fully assembled and ready to use. This section will guide you through a few simple steps to assist you in setting up your Ankle Attacker. Please follow all instructions. They are important for the safety of everyone.

- 1. Unpack product from box. If product has any shipping damage please contact C-Tech Entertainment FX immediately.*
- 2. Determine the location you would like to install the Ankle Attacker.*
- 3. Using a pencil mark the wall panel where the output mounting ring will mount. If the Ankle Attacker is on a flat surface the output hole will be marked at 14.5". Always check measurements before drilling any holes.*
- 4. Using a 1" hole saw, drill a hole for the air output.*
- 5. Using a 1/4" bit, drill the (4) holes for the output mounting ring.*
- 6. Mount the output mounting ring to the wall panel using the supplied hardware. **NOTE:** The washers and nuts should be installed on the rear of the wall panel. It is recommended that you countersink the heads of these screws. (Use 3/8" drill bit for countersink holes)*
- 7. Using the mounting feet located on the bottom of the air reserve tank, mount the Ankle Attacker to a stable surface. It is very important that the Ankle Attacker be properly secured. If it not mounted properly, it will move each time it is fired.*
- 8. Connect a female air fitting from your air compressor hose to the male fitting on the rear of the Ankle Attacker.*
- 9. Power up your air compressor and allow the Ankle Attacker reserve tank to fill. You may use the regulator on your compressor to adjust the tank pressure. **CTE recommends 80-100 PSI. However, you can set the regulator to the setting that works best for your application. The components used in the Ankle Attacker are rated for 100 PSI MAXIMUM. DO NOT EXCEED 100 PSI.***
- 10. Connect the Ankle Attacker power cable into a standard 110VAC power source. Once the Ankle Attacker reserve tank is full, it is ready for operation. To activate the Ankle Attacker, press the trigger button on the handheld remote. When the trigger button is pressed, the Ankle Attacker will fire immediately.*

**If you would like to automate this effect, you can purchase an add-on controller from C-Tech Entertainment FX. For optional accessories visit <http://www.ctechentertainmentfx.com>**

**WARNINGS:**  
**IMPORTANT PLEASE READ**  
**By purchasing this product you have agreed to the following:**

**Ankle Attacker was designed to be used near adults only.**

Ankle Attacker must be allowed to recharge before re-firing.

**Ankle Attacker is a startle “PROP” and should never be used as a weapon or toy.**

Ankle Attacker is extremely loud, ear protection should be worn whenever possible.

**Ankle Attacker should never be subjected to rain or excessive moisture.**

Never exceed maximum pressure rating of 100 PSI.

**Never insert any object into the valve outlet.**

Never attempt to fire any object from the Ankle Attacker.

**Always secure the unit to the ground or a stationary wall.**

Always use at ground level output pipe pointing no higher than knee level.

**Always disconnect power and air when not in use.**

C-Tech Entertainment Products LLC, employees, suppliers and affiliates are not responsible and/or liable for any damage or injury caused by the Ankle Attacker.

**Limited Warranty for C-Tech Entertainment Products LLC:**

C-Tech Entertainment Products LLC ("CTE") provides the following Limited Warranty C-Tech Entertainment Products LLC (excluding spare parts and consumables) distributed by CTE or through our authorized distribution channels:

CTE warrants that a C-Tech Entertainment product, from the time of sale through the Limited Warranty period of one (1) year, will be free of defects in materials or workmanship and will conform to the performance specifications applicable for the particular C-Tech Entertainment product.

All C-Tech Entertainment products are subject to the Warranty Exclusions described below. A C-Tech Entertainment product or component found to be defective will be repaired or replaced with new or refurbished product or component at CTE's option.

Purchasers may obtain warranty service and further information within the applicable Limited Warranty period for the C-Tech Entertainment product purchased by calling (612) 735-7351 or by email [techsupport@ctechentertainmentfx.com](mailto:techsupport@ctechentertainmentfx.com).

Proof of purchase is required to demonstrate eligibility for warranty service. Warranty claims must be made directly to C-Tech Entertainment Products LLC

**Warranty Exclusions**

Limited Warranty does not apply to a C-Tech Entertainment product that has been subjected to physical damage after purchase, caused, for example, by casualty, accident, acts of God or transportation, including (a) by a failure to properly package and ship the product back to CTE for warranty service in accordance with CTE's packaging and Shipping Guidelines.; (b) from service, modification or repair not performed by CTE or a service provider authorized by CTE or by tampering, use of counterfeit or other non CTE approved components, assemblies, accessories, or modules; (c) by misuse, unreasonable handling or maintenance, mistreatment, operator error, failure to provide proper supervision or maintenance.

