



## Web Gun CTE-WBGA

Thank you for your purchase. The CTE Web Gun is a device for haunted house use. The Web Gun is a great addition to any special effects toolbox. The Web Gun runs on standard 110VAC power and compressed air. The Web Gun will produce realistic, durable spider webs.

CTE constructs products using high quality components and parts. The Web Gun was designed and built to last many years. All CTE products carry a one (1) year warranty.

The CTE Web Gun is shipped assembled and ready to use. You will need to supply a standard air compressor and 110VAC. The following section will guide you through a few simple steps to assist you in setting up your Web Gun. The Web Gun is not intended to be used on people or animals. The Gun will be extremely hot when powered on. Web material can damage some surfaces. Always test the surface before using. Please use caution when using this device. Please follow all instructions. They are important to the safety of everyone.

- 1. Unpack product and inspect for damage. If device is damaged, please contact CTE immediately.*
- 2. Insert a Web Stick into the rear of the gun.*
- 3. Connect the Web Gun to a standard 110 VAC electrical outlet. Allow Gun to heat for approx. 5-10 minutes.*
- 4. Connect a female air fitting from your air compressor hose to the male fitting on the bottom of the Web Gun.*
- 5. Power up your air compressor and allow the tank to fill. You may use the regulator on your compressor to adjust the output pressure. CTE recommends 90-110 PSI. However, you can set the regulator to the setting that works best for your application. **The components used in The Web Gun are rated for 110 PSI MAXIMUM. DO NOT EXCEED 110 PSI.***
- 6. Once your air compressor tank is full, the Web Gun is ready for operation. Turn the ball valve to the on position. Gently squeeze the trigger and move the gun in a back and forth motion.*

**The Web Gun needs consistent pressure to operate properly. If pressure drops, discontinue use and wait for the pressure to restore. Occasionally, the Gun will clog. Use a cloth to gently clean air tube and silver dispenser nozzle. Exercise extreme caution when doing this. Components will be hot!**

**WARNINGS:**  
**IMPORTANT PLEASE READ**  
**By purchasing this product you have agreed to the following:**

- Never point the Web Gun towards anyone.
- The Web Gun is designed to be used by adults only.
- Eye protection should be worn during use.
- Never exceed maximum pressure rating of 110 PSI.
- Always disconnect power and air when not in use.
- The Web Gun should never be subjected to rain or excessive moisture.

C-Tech Entertainment Products LLC, employees, suppliers and affiliates are not responsible and/or liable for any damage or injury caused by this device.

**Limited Warranty for C-Tech Entertainment products:**

C-Tech Entertainment ("CTE") provides the following Limited Warranty C-Tech Entertainment Products (excluding spare parts and consumables) distributed by CTE or through our authorized distribution channels:

CTE warrants that a C-Tech Entertainment Product, from the time of sale through the Limited Warranty period of one (1) year, will be free of defects in materials or workmanship and will conform to the performance specifications applicable for the particular C-Tech Entertainment Product.

All C-Tech Entertainment Products are subject to the Warranty Exclusions described below. A C-Tech Entertainment Product or component found to be defective will be repaired or replaced with new or refurbished product or component at CTE's option.

Purchasers may obtain warranty service and further information within the applicable Limited Warranty period for the C-Tech Entertainment Product purchased by calling (612) 735-7351 or by email CTEProducts@aol.com.

Proof of purchase is required to demonstrate eligibility for warranty service. Warranty claims must be made directly to C-Tech Entertainment.

**Warranty Exclusions**

Limited Warranty does not apply to a C-Tech Entertainment Product that has been subjected to physical damage after purchase, caused, for example, by casualty, accident, acts of God or transportation, including (a) by a failure to properly package and ship the product back to CTE for warranty service in accordance with CTE's packaging and Shipping Guidelines; (b) from service, modification or repair not performed by CTE or a service provider authorized by CTE or by tampering, use of counterfeit or other non CTE approved components, assemblies, accessories, or modules; (c) by misuse, unreasonable handling or maintenance, mistreatment, operator error, failure to provide proper supervision or maintenance.